

Solar & Safety Films - Installation Preparation

Please review the following items. They will help minimize disruptions and streamline the installation of your new Solar window film. A discussion with your installer concerning installation preparation is strongly advised.

Nick Knacks & Window Treatment - Remove all items such as plants, pictures, and miscellaneous nick knacks from the windowsills and surrounding area. It is also wise to position window treatments to allow for easy access to the windows. Window treatments may occasionally require removal to accommodate the installation process. This should be discussed on the estimate proposal agreement.

Furniture - Remove and/or re-arrange any furniture that may hinder the installer's access to the windows. The installer may need to move heavy furniture. This should be discussed and noted on the estimate proposal agreement as well.

Airborne Contamination / Pre-Installation Inspection - To minimize airborne contamination during installation, close all air conditioning and heavy vents in the vicinity of the windows scheduled for film installation. This will reduce the amount of dust and lint in the air. It is also wise to clean floors and vacuum carpeting a day before the film installation begins. Remove all pets from the facility during installation.